

USB to RS-485 Adapter with Terminal Block Changer

USB to RS-485 adapter provides an extra serial com port via USB connection and can be configured to work with RS-485 peripherals such as POS and industrial controlled devices. The USB adapter supports an easy serial port expansion and requires no IRQ, DMA, or I/O port resources.

The USB adapter features a full set of RS-485 data and control signals on its DB-9 or terminal block changer. It supports data transfer rates of up to 3M baud. It receives full power via the host USB connection, and provides power to the attached serial device without requiring an external power adapter.

Features:

- Fully Compliant with USB specification 1.1 and 2.0
- Allows up to 256 nodes on the bus
- $\pm 15\text{kV}$ HBM ESD Protected
- Supports data transfer rates up to 3M baud
- Supports remote wake-up and power-on-reset
- Compatible with Windows 98SE / ME / 2000 / XP / Vista / 7 / 8 / 8.1 / 10 or higher, Win CE, Windows server 2003 / 2008 / 2008R2 / 2012 / 2012R2 or higher; Mac OS 8.6 / 9.x / 10.x, Linux 1.5.0 or higher
- Changer adapter from DB-9F to 5 Pins Terminal block

Specification

Model No.		UTS-485X + DT485C	Pin Assignment		
Chip		FTDI	Pin No.	DB-9M	Terminal Block
Data Transfer Rates		Up to 3 M baud	1	B-	A+
Power Consumption		56mA	2	B+	B-
LED		3	3	Non	G
Environment	Operating Temp.	0 °C ~ 40 °C	4	Non	120Ω
	Storage Temp.	-20 °C ~ 60 °C	5	GND	
	Humidity	0~80% RH, Non-condensing	6	120Ω	
USB Specification		USB 1.1/2.0 compliant	7		
Interface		RS-485	8	Non	
Connector	Host	USB Type A Male	9	Non	
	Device	DB-9M / DB-9F to Terminal Block			
Power Mode		Bus powered			
Housing		Plastic			

